


Parts Legend



- 1. BARREL
- 2. BACKSIGHT
- 3. BACKSIGHT SPACER
- 4. BACKSIGHT HINGE PIN
- 5. BACKSIGHT DETENT PLUNGER
- 6. BACKSIGHT DETENT PLUNGER SPRING
- 7. BACKSIGHT HINGE PIN LOCK PIN
- 8. BOLT RELEASE STOP
- 9. BOLT RELEASE
- 10. BOLT RELEASE SPRING
- 11. BREECHBOLT
- 12. BREECHBOLT HEAD
- 13. BUTTPAD ASSEMBLY
- 14. BUTTPAD ASSEMBLY RETAINING SCREW, TOP
- 15. BUTTPAD ASSEMBLY RETAINING SCREW, BOTTOM
- 16. BUTTSTOCK
- 17. COCKING PIECE
- 18. EJECTOR SCREW
- 19. EXTRACTOR
- 20. EXTRACTOR SCREW
- 21. EXTRACTOR SPRING

- 22. FLASH ELIMINATOR
- 23. FORE-END ASSEMBLY
- 24. FORESIGHT ASSEMBLY
- 25. FRONT GUARD SCREW
- 26. GUARD SCREW LOCK WASHER
- 27. HANDGUARD
- 28. LOCKING BOLT
- 29. LOCKING BOLT SCREW
- 30. LOCKING BOLT SPRING
- 31. MAGAZINE BODY
- 32. MAGAZINE CATCH
- 33. MAGAZINE CATCH SCREW
- 34. MAGAZINE FOLLOWER
- 35. MAGAZINE SPRING
- 36. MAINSPRING
- 37. REAR GUARD SCREW
- 38. RECEIVER
- 39. SAFETY CATCH
- 40. SEAR
- 41. SEAR HINGE PIN
- 42. SEAR SPRING
- 43. SLING SWIVEL
- 44. STRIKER
- 45. STRIKER SCREW
- 46. SWIVEL BAND
- 47. SWIVEL BAND SCREW
- 48. STOCK BOLT AND LOCK WASHER
- 49. TRIGGER
- 50. TRIGGER GUARD
- 51. TRIGGER PIN